


American Retail Supply Assembly Instructions

Garment Racks - 428401, 428402, 428409, 428410



Parts list

- 2 End-Frame Uprights
 - 4 Arms
 - 1 Cross Brace (Stretcher)
 - 2 Connectors for Base
- Misc. bolts, washers, set screws
Screws are in the ends of the connecting bars

1. See Diagrams - assemble end frame upright and base connectors with bolts and washers. **Make sure adjustment holes on uprights are facing inward.**

2. Install the cross brace (stretcher) with bolts and washer between the end frames as shown.

3. Thread four leveler feet (or optional casters) into base and adjust level for any floor variations.

4. The arm pieces have a push-button adjuster; orient these so the push-button will match up with the adjustment holes, insert into the uprights from the top. The push-button will click into adjustment holes; to reposition, press button and move arm up or down to another height. Each arm can be set at a different height if desired.

5. When first loading the fixture, balance the weight! Put heaviest and largest items on lower arms near the center.

End-Frame/Upright Diagram:

